


This document is not typically left with the user as it contains information on setting values which, if not correctly set may damage the heating, cooling or air conditioning system or seriously affect its performance or energy consumption. Great effort has been taken to making the A4100 thermostat system intuitive, reliable and easy to install. Using a common sense approach to the installation will ensure this product is installed easily and to the customer's satisfaction. Please read and understand this instruction manual so that installation, testing and commissioning process is undertaken in an efficient and effective manner. This manual is to be used in conjunction with the supplied user manual. Great care has been taken in the preparation of this manual. It is the responsibility of the user to ensure this thermostat, or the equipment connected to it is operating to their respective specifications and in a safe manner.

**Installation**

- As with any air conditioning project undertaken, careful installation is the key to a successful outcome. Time taken during this installation process will be rewarded by a happy customer and fewer call backs. The steps required to install the A4100 thermostat are
1. Read and understand this manual and the User manual.
  2. Mount the A4100 back plate in a suitable location.
  3. Set the 8 DIP switches to match the need of the project / user.
  4. Wire the optional remote temperature sensor(s) or switches if required.
  5. Power up the air conditioning system.
  6. Set the installer software options (if required).
  7. Program and set up the A4100 thermostat. (The User Manual will assist with this).
  8. Test the heating, cooling and other functions – Commissioning.

For convenience the layout of this manual is in the same order as the steps listed above.

**Mounting the wall controller**



The A4100 can only be as accurate as the onboard temperature sensor, or its optional remote temperature sensor(s) permit. It is therefore essential that the wall thermostat be installed in a location that is typical of the ambient room temperature. Do not install the thermostat in a draft, near a floor, behind doors, or on a non insulated external wall. Also avoid placing the thermostat in areas where the air movement is limited, affected by direct sunlight or other areas not "typical" of the temperature of the room. Further, when mounting the A4100 be aware that drafts may travel down the inside of cavity walls, (especially if mounted on external walls) and enter the back of the thermostat or sensor enclosure through the cable entry holes in the wall. It is important to fully seal these holes to prevent any drafts affecting the internally mounted temperature sensor. It is recommended to mount the A4100 or remote sensors between 1.5 & 1.7 metres from the floor where possible. Move the control wires through the large opening in the thermostat base plate then place the thermostat base on the wall and using appropriate screws, firmly attach the thermostat base to the wall. Seal any holes where cables enter the back of the thermostat to prevent drafts entering through these holes affecting the sensor.

**Setting the hardware switches**

Switch	Off	On
Sw1 – Fan Speeds	1 Speed Fan (2 heat / 2 Cool)	3 Speed Fan (1 heat / 1 Cool)
Sw2 – Equipment Type	Heat Cool	Heat Pump (O/B terminals)
Sw3 – Stages	1 Stage	2 Stages
Sw4 – Reversing Valve If Sw 2= ON – Heat Pump Sw4 – Fan Mode If Sw 2= OFF – Heat/Cool	Energise in cool (O) Fan Control by Heater (HG)	Energise in heat (B) Fan Control by T'stat (HE)
Sw5 – Anti cycle timer	Off	4 Minutes
Sw6 – Operation	Manual Thermostat	Programmable Thermostat
Sw7 – Minimum Run	2 minutes	6 Minutes
Sw8 – Program Type If Sw 6= ON – Programmable Sw8 – Set points If Sw 6= OFF – Manual	Commercial Program Single Set point	Residential Program Two Set points

Typical drawings have been provided on of this manual that will assist with the selection of the correct positions for these function switches.

- Switch 1 – Relay Assignment The A4100 is fitted with 5 relays capable of switching up to 24VAC @ 1Amp. Switch 1 sets the function as either 3 fan speeds with 1 heat and 1 cool operation or single fan speed with 2 heat and 2 cool, in either HP (Heat pump or reverse cycle) or HC (heat with add on cool) mode.
- Switch 2 – Equipment Type. Both heat with add on cool or heat pump types of systems can be controlled by the A4100. Heat Cool System uses the "W" terminals only for heating and the "Y" terminals only for cooling. Heat Pump systems use the "Y" terminal(s) for BOTH heating and cooling. The "W1" terminal to control the reversing valve which determines heating or cooling mode.
- Switch 3 – Equipment Stages. When it is necessary to control a single stage system A/C system fitted with auxiliary heating elements, turn sw3 OFF thereby selecting single stage mode. Heating elements are now called as stage 2 heat (NOT Stage 3 eat).
- Switch 4 – Reversing valve or Fan mode When the A4100 is set for Heat Pump mode (Sw2 is on) then this switch sets the reversing valve logic (O/B). When the A4100 is set for Heat Cool Mode (Sw2 is off) then this switch sets the mode for the Heater fan logic (HG or HE mode).
- Switch 5 – Anti Cycle Timer To protect some A/C systems it is preferred that under no circumstances should the compressor start within 4 minutes of it switching off. Note, when power is first applied to the A4100 it "assumes" that the compressor has just stopped and applies this anti cycle delay time before starting.
- Switch 6 – Thermostat Operation To suit the varying requirements of the user, the A4100 can be set as a programmable thermostat using the time clock to automatically control the building temperature to a programmed temperature profile, or to the very simple to operate manual mode where the user turns the thermostat on or off, and adjusts the temperature set point manually.
- Switch 7 – Minimum Run time. To conserve energy and protect the A/C system it is recommended to limit the number of times the heating and or cooling system can run in 1 hour. This switch sets the minimum heating and cooling equipment to a minimum run time of 2 or 6 minutes. Once the heating or cooling has started it must run for this minimum set time. The LCD will flash the word "Heating" or "Cooling" when ever this timer is in effect.

Switch 8 – Thermostat Control Logic. This switch also has two functions based on the position of switch 6. When the A4100 is set as a programmable thermostat switch 8 determines whether commercial program or residential program is selected. When switch 6 has the A4100 used as on programmable thermostat, this switch sets single set point mode (imitating a simple mechanical thermostat) or whether a separate heating and cooling set point can be selected by the user. Two set point mode also permits the user to select a separate day and night set point if required.


**TT terminal Functions**

The A4100 is fitted with a set of terminals marked "TT". Detail on the functions that the "TT" terminals perform is provided below. See the advanced installer setting menu of this manual for setting the function of this set of terminals. The wiring used in the following examples are not polarity dependent and do not normally require screened cable.

NOTE: The A4100 can use multiple sensors if required. Drawings showing these various configurations re shown on of this manual.


**Outside Air Sensor wiring**

Set "TT= OA" in the advanced installer menu. The A4100 can display the outside air Temperature if desired. Some advanced control functions such as high and low balance points rely Figure 1 on this sensor to be fitted for correct operation. Using a single pair of wires connect the "TT" terminals in the A4100 to the two terminals in the outside air temperature sensor. (See figure 1). If the outside air sensor fails two dashes will be shown on the LCD where the outside air temperature would normally be displayed to alert you of the problem.



**Remote Air Temperature sensor wiring.**

Set "TT= RS" in the advanced installer menu. When you wish to measure the temperature from a location distant from the wall controller, simply connect a remote temperature sensor to the "TT" terminals in the A4100. This will automatically disable the sensor fitted to the wall controller and use the remote temperature sensor(s) to control the room temperature (See figure 1 above). Should you wish, you can easily switch the remote temperature sensor on and off thereby switching temperature sensing locations between the remote temperature sensor and the A4100 temperature sensor when required.




**Averaging Temperature sensors**

Set "TT= AV" in the advanced installer menu. The A4100 can average the sensor temperature equally between the remote temperature sensor(s) and the one fitted to the A4100 if required. See figure 1 on the previous for details on wiring the sensor. The A4100 will auto detect this sensor and automatically average the two sensors values to control the room temperature.

**Remote ON / OFF function**

Set "TT= OF" in the advanced installer menu. The A4100 can be connected to an external dry contact, when this contact is closed the A4100 will turn OFF. See figure 3. When the A4100 has been switched OFF via the "TT" terminals the word "OFF" will flash in the LCD to indicate that this has been the shutdown method. The A4100 will return to the user settings when this switch is open.



**Using the "Occupancy Mode"**

Set "TT= OC" in the advanced installer menu. The A4100 can alternate between the user preferred set points and an installer pre programmed set point when required. Simply wire a remote switch to the A4100 "TT" terminals, (see figure 3). When the switch is open the user settings will control the room temperature, when the switch is closed the Installer "Oc" (Occupied Cooling value) & "Oh" (Occupied Heating value) settings will be used to control the room temperature.

**Typical Drawings**

The A4100 has the capacity to control a wide selection of heating, cooling and air conditioning systems. Using the DIP switches and installer software options, the A4100 is capable of providing more than 96 different control methods from its 5 fitted relays. Examples of only the most common types of control wiring have been provided below.

**1 Heat with add on cool**

**Switch Settings**  
Sw1 = Off (1 speed fan)  
Sw2 = Off (HC System)  
Sw3 = Off (Single Stage)  
Sw4 = OFF (HG)  
Sw5 = Installer preference  
Sw6 = User requirements  
Sw7 = Installer preference  
Sw8 = User requirements

**2 stage gas heat 1 stage add on cool**

**Switch Settings**  
Sw1 = Off (1 speed fan)  
Sw2 = Off (HC System)  
Sw3 = On (Two Stage)  
Sw4 = OFF (HG)  
Sw5 = Installer preference  
Sw6 = User requirements  
Sw7 = Installer preference  
Sw8 = User requirements

**1 stage reverse cycle 3 speed fan**

**Switch Settings**  
Sw1 = On (3 speed fan)  
Sw2 = On (HP System)  
Sw3 = Off (One Stage)  
Sw4 = Equipment Specific  
On = B Off = O  
Sw5 = Installer preference  
Sw6 = User requirements  
Sw7 = Installer preference  
Sw8 = User requirements

**2 stage Heat Pump with Emergency Heat**

**Switch Settings**  
Sw1 = Off (1 speed fan)  
Sw2 = On (HP System)  
Sw3 = On (Two Stage)  
Sw4 = Equipment Specific  
On = B Off = O  
Sw5 = Installer preference  
Sw6 = User requirements  
Sw7 = Installer preference  
Sw8 = User requirements

**Note: Set W3=EH in installer menu.**

**1 stage Heat Pump with Auxiliary Heat 1 speed indoor fan**

**Switch Settings**  
Sw1 = Off (1 speed fan)  
Sw2 = On (HP System)  
Sw3 = Off (One Stage)  
Sw4 = Equipment Specific  
On = B Off = O  
Sw5 = Installer preference  
Sw6 = User requirements  
Sw7 = Installer preference  
Sw8 = User requirements

**Note: Set W3=OF in installer menu.**

**1 stage reverse cycle 2 speed fan**

**Switch Settings**  
Sw1 = On (3 speed fan)  
Sw2 = On (HP System)  
Sw3 = Off (One Stage)  
Sw4 = Equipment Specific  
On = B Off = O  
Sw5 = Installer preference  
Sw6 = User requirements  
Sw7 = Installer preference  
Sw8 = User requirements

**Attaching the thermostat**

Check that the position of the 8 DIP switches matches the requirements of the equipment being controlled and the specific requirements of the user. Detailed information on the 8 DIP switches can be found on this manual. Check the wiring matches that of the equipment the A4100 is to control and that all wiring is tight and not likely to short between adjacent wires. Equipment wiring information can be found of this manual. If using the Modbus communication capability of the A4100, ensure the "A", "B" & "C" data wires are in the correct position as an error here may affect the communication of the entire network. Using masking tape or similar, block the hole in the wall where the wiring enters the back of the thermostat to prevent drafts that may travel down the inside of the wall cavity from affecting the accuracy of the internally fitted temperature


Remove and discard the plastic tab on the internally fitted backup battery so that the battery is now in circuit and operating. Avoid twisting the case as this may stress the LCD and cause it to crack. Avoid running wiring near the internally fitted sensor.

Take care not to damage or crush the temperature sensor between the two half's of the case when you close the Chameleon case. Check this sensor location.

**Advanced Installer Settings**

The A4100 is fitted with many advanced functions that can be fine tuned by the installer to specifically match the needs of the project of the user. Normally these functions will not need to be altered from the factory default position however, there may be times when you wish to alter a setting or control capability so that the A4100s performance will perfectly match a particular application. While in the advanced installer menu, all A4100 equipment control functions will be suspended. Normal equipment operation will continue when you have exited this menu (after any anti cycle delays or safety delays have terminated).

**Using the Installer Menu**




To adjust a value in the Installer menu tap the UP or DOWN keys. To exit the installer menu tap the "DONE" key or wait 60 seconds. Entering the Installer Menu To enter the Installer menu, press and hold the PROG DAY key for 30 seconds. After 6 seconds the LCD will show "88:15" – The factory default Adjust this value to "88:21" (or your previously selected value) by using the up or down key. Tap the DONE key to enter the menu.

If you have entered the correct PIN you will be given the first menu option, if you have entered an incorrect PIN you will be exited from this menu. Default Installer Values are shown in the examples below.

**PN =21 Keyboard Lock PIN**

This is the required PIN for future entry into the Installer menu. Range 00 to 99 in 01 steps. (Caution, if you change this value and forget your new PIN, you may need to return the A4100 to place of purchase for unlocking there may be a fee for this service.)



**LC=0 Keyboard Lock level**

**Programmable Mode (SW6=ON)**  
LC=0 Key board Lock OFF. LC=01 All keys are locked.

**HL=35 (95F) Heating Limit (or High Limit)**

The highest Heating value permitted to be set by the user. Adjustable between 0–35c (32–95F).

**CL =5 (41F) Cooling Limit (or Low Limit)**

The lowest Cooling value permitted to be set by the user. Adjustable between 5–37c (41–98F).

**CF=C Temperature display**

Format Deg C or deg F display type. (effects all user and installer menu items)

**C1 =0.0 Fitted Sensor Calibration**

Calibration Offset for the internal sensor. Adjustable range +/- 5 deg C (+/- 9 F).

**tC =12 Time Clock**

Display 12 or 24 hour Clock Style.

**tD =0 Temperature Display**

TD=00 The A4100 will display both the Room & Set Temperature. TD=01 The A4100 will display set temperature only.

**AH=2 After Hours Override Timer**

DAY / EVENING Mode Commercial Thermostat Mode (Sw6=on, Sw8=off) After hour run time period Adjustable range 0 (off) to 12 hours. Setback (1, 2, 3, 4) mode – Residential programmable Mode (Sw6=on, Sw8=on) Temporarily program override period. Off= Override till next program change or 1 12 hours (fixed time override).

**SC=OFF Stop Cooling temperature**

Start/stop mode Only. (Sw6=on, Sw8=off). Cooling temperature that will be maintained when running the "STOP" program. (Night Setback) Adjustable between 5–37c. (41–98F) + OFF.

**SH= OFF Stop Heating temperature**

Start/stop mode Only. (Sw6=on, Sw8=off). Heating temperature that will be maintained when running the "STOP" program. (Night Setback) Adjustable between 5–37c. (41–98F) + OFF. Db=1 Single Set Point Dead band. Dead band between heat and cool set point when in single set point mode (sw8 off). Adjustable between 0 and 5 deg.

**FO=0/2 Fan Options Advanced Fan Functions**

This function is only enabled when the selected fan mode is Fan On. "FAN ON" will be displayed in the LCD to confirm the mode. FO=0 (Default).The fan will run continuously . 24 hours a day 7 days a week.

FO=1 The fan will continue to run after the cooling stops to ensure the maximum fresh air ventilation and to aid in cooling. The fan will stop after the heating stops. (This is done to prevent cold drafts that may occur on cold days when A/C system is heating). FO=2(Default in Start Stop Mode).Available only if in Programmable Mode (Sw6=on). The Fan will Run continuously from program # 1 (or Start) Program to program #4 (or Stop) program and then run in AUTO mode overnight to maintain the night time set points.

FO=3 Available only if in Programmable Mode (Sw6=on). This mode is the combination of option 1 and option 2 given above.

**FP=1 Fan Purge Time Period (Fan run on)**

If fan mode is Auto Fan, the indoor fan will run for FP=XX minutes after heating or cooling has stopped to extract any stored energy in the coils etc – (Necessary for electric element heating). Adjustable between off to 5 minutes in 1 minute intervals.

**Fn=A Function Available Equipment Modes**

FN=A Select if controlling a Heating & Cooling system.  
FN=C Select if controlling a Cooling only system. (disables heating menus)  
FN=H Select if controlling a Heating only system. (disables cooling menus)  
H3=Of W2 relay Function

Only operates in single fan speed HP mode. (Sw 1=off & Sw2=on).

H3=Of W2 relay is used as 2nd (or 3rd) stage Auxiliary heat.

H3=EH W2 relay is used to control an Emergency Heating system.

H3=AH W2 relay is used to control a Add On Heat system.

**tt=RS TT terminal Function**

TT=OA Connect the outside air temperature sensor to the TT terminals to display the outside Air Temperature. (Required for all outside air control functions to operate.)

TT=RS Connect the remote room temperature sensor to the TT terminals to measure the temperature at a remote location away from the A4100. (Note: This completely disables the temperature sensor fitted to the A4100)

TT=AV The TT terminals will average the temperature measured by the A4100 internal sensor and remote room temperature sensor.

TT=OF – A closed contact on the TT terminals will switch the A4100 On or OFF.

TT=OC A closed contact on the TT terminals will switch the A4100 to Occupied Mode, where the oC & oH temperatures will replace the user set temperatures.

**AF=0 Anti Freeze Function**

AF=0 Antifreeze function off.

AF=1 Room temperature will not be permitted to fall below 5c (41F).

**oH=OFF Occupied Mode Heat Set**



